

## TORQUE SPECIFICATION

Part tightened	N·m	kgf·cm	ft·lbf	
Extension housing x Transmission case	34	345	25	
Transmission mounting bracket x Extension housing	12	120	9	
Engine rear support member x Frame	25	260	19	
Engine rear support member x Transmission mounting bracket	13.5	135	10	
Transmission mounting bracket x Transmission Case	12	120	9	
Vehicle speed sensor set bolt	5.4	55	48 in.·lbf	
O/D direct clutch speed sensor set bolt	5.4	55	48 in.·lbf	
ATF temperature sensor connector set bolt	5.4	55	48 in.·lbf	
Drain plug	20	205	15	
Shift solenoid valve SLU and SLT set bolt	6.4	65	56 in.·lbf	
Shift solenoid valve SLN and No. 4 set bolt	10	100	7	
Shift solenoid valve clamp set bolt	6.4	65	56 in.·lbf	
Shift solenoid valve No. 1 and No. 3	6.4	65	56	
Shift solenoid valve No. 2	10	100	7	
Shift control rod set nut	13	130	9	
Valve body x Transmission case	10	100	7	
Oil pan x Transmission case	7.4	75	65 in.·lbf	
Oil strainer x Valve body	10	100	7	
Parking lock pawl bracket x Transmission case	7.4	75	65 in.·lbf	
Control shaft lever set nut	16	163	12	
Shift lever guide housing assembly x Shift lever plate	4.9	50	43 in.·lbf	
Floor shift lever assembly set bolt	8.3	85	73 in.·lbf	
Transmission oil cooler x cylinder block	29	296	21.4	
Oil cooler pipe clamp bolt	5.4	55	48 in.·lbf	
Oil cooler pipe union nut	44	450	33	
Transmission x Engine	14 mm head	37	380	27
	17 mm head	72	730	53
Starter x Transmission	37	380	27	
Exhaust pipe assembly x Exhaust manifold	62	632	46	
Exhaust manifold with TWC x Engine	39	400	29	
Pipe support bracket x Transmission	43	438	32	
Torque converter x Drive plate	48	490	35	
Propeller shaft x Differential	74	750	54	
Propeller shaft x Body	49	500	36	
Drive plate x Crankshaft	83	850	61	